



Keyboard Mechanical Zeroground KB-2400G TAIGEN v2.0



Overview:

Aluminium Gaming MECHANICAL Keyboard KB-2400G TAIGEN V2.0 Get a higher precision on your keystrokes with TAIGEN

Ultra comfort, outstanding performance and attractive appearance, excellent touch.

Packed with gaming features and good looks, TAIGEN is designed to provide everything gamers need at a price that won't break the bank.

Customizes **RGB led colors- 6** keys modes

LED back light illumination

1.5m nylon cable

USB 2.0 golden plated connector

Material: ABS

Key features:

Size: 444(L) x 205(W) x 39(H) mm

Weight: 863gr

Keys: 104

Operation force: 55 ± 7gr max

Maximum use life : 20 million keystrokes

Connection: USB

Compatible with: Windows

2000/xp/vista/2003/2007/win7/win8/win10/mac

LED back light illumination

1.5m nylon cable

USB 2.0 golden plated connector

Material: ABS



©2011 Pc-professional Products. All rights reserved.

All brand names are registered trademarks of their respective owners.

Specifications are subject to change without prior notice.

COMBINATION KEY FUNCTIONS:

N+INS=Change LED colors (9 display modes)
FN+1=Gaming mode 1 (FPS)-ASDW ↑ ↓ ←→ ESC lighted
FN+2 =Gaming mode 2 (CF)- ASDW ctrl Shift Alt space RGQEB 1-5 Home
End PgUp PgDn lighted
FN+3 =Gaming mode 3 (COD)-QWERTASDGCV 1-7 Shift lighted
FN+4 =Gaming mode 4 (RTS)-QWERTASDGXZKFLHMUYTP Space 1-0 Ctrl Shift Alt lighted
FN+5 =Gaming mode 5 (LOL all)-QWER DGFBV Ctrl Alt Tab Space~1-6 Esc lighted
FN+6 =Gaming mode 6 (Car race)-ASDWR↑ ↓ ←→Ctrl Shift Alt lighted
FN+7 =Gaming mode 7 (N B A)-AFSWRE Space ↑ ↓ ←→ZXCV 1234 Ctrl Shift Alt lighted
FN+8 =Gaming mode 8 (LOL)-QWERDFB1-6

CUSTOMIZED LED COLORS:

Step 1.Press FN+Home (NumLock, CapsLock, Scroll Lock flicker)
Step 2.Light the keys which need be customized
Step 3.Press FN+End=Storage(CapsLock, Scroll Lock off)
Step 4.Press FN+9 (Customized LED colors)
FN+PAU=LED on/off
FN+PG UP=Brightness+
FN+PG DN=Brightness-
FN+↑ , FN+↓ =Speed
FN+WIN=Lock WIN/APP key
6 keys mode: Press FN+PRT+NumLock+CapsLock+ScrollLock Flicker two seconds
N keys gaming mode : Press FN+SCR+NumLock+CapsLock+ScrollLock Flicker four seconds

MULTIMEDIA FUNCTION:

FN+F1 Media
FN+F2 Volume –
FN+F3 Volume +
FN+F4 Mute
FN+F5 Stop
FN+F6 Previous track
FN+F7 Play/Pause
FN+F8 Next track
FN+F9 E-mail
FN+F10 Web
FN+F11 My computer
FN+F12 Calculator

Information:

Manufacturer site: www.pc-professional.info

